

# Quick Start Guide

# InSight Series Bullet Network Camera

\*Images may differ from actual products. InSight S345S is used for demonstration in this guide.


## Contents

Chapter 1	Appearance	1
Chapter 2	Installation ————	3
2.1	Safety First	3
2.2	Mount the Camera	3
2.3	Install microSD Card (Optional)	6
2.4	Connect Alarm (Optional)	7
2.5	Waterproof (Optional)	7
Chapter 3	Configuration ————	8
Appendix FAQ 1		10

# Chapter 1 Appearance

The figure is for demonstration purposes only. Your device may differ in appearance from the depicted.

InSight S345 / InSight S355 / InSight S385



- 1 IR LED
- 2 Microphone

③ **Reset:** Unfasten the two fixed screws to remove the cover. Press for 5 seconds to reset the camera to factory settings.


- (4) Speaker
- (5) RJ45 Network Interface (supports PoE)
- 6 Lens
- **7 White LED**

(8) **microSD Card Slot:** Unfasten the two fixed screws to remove the cover. Insert a microSD card for local storage. Initialize the SD card via VIGI app or other management tools before recording videos.

#### (9) Power Supply Interface

\*The camera comes with a lightning protection mechanism. You can ground the camera with ground wire.

## InSight S345S



## 1 IR LED/White LED × 2

2 **Reset:** Unfasten the two fixed screws to remove the cover. Press for 5 seconds to reset the camera to factory settings.

- **3** Speaker
- (4) Lens
- **5** Built-in Microphone

6 **microSD Card Slot:** Unfasten the two fixed screws to remove the cover. Insert a microSD card for local storage. Initialize the SD card via VIGI app or other management tools before recording videos.

- ⑦ RJ45 Network Interface (supports PoE)
- **8** Alarm Interface
- 9 Power Supply Interface

\*The camera comes with a lightning protection mechanism. You can ground the camera with ground wire.


## **Chapter 2 Installation**

#### 2.1 Safety First


- Make sure your power supply matches your camera. The power source should comply with Power Source Class 2 (PS2) or Limited Power Source (LPS) of IEC 62368-1.
- Make sure that the wall is strong enough to withstand 4 times the weight of the camera and mounting bracket.
- Make sure the device is not connected to a power source when mounting and connecting cables.
- If you are uncertain or uncomfortable performing the installation, consult a qualified electrician.

## 2.2 Mount the Camera


1. Get ready




2. Choose the mounting method.




- 3. Mount the camera according to your desired mounting method.
- Option 1 Ceiling Mounting




Option 2 Wall Mounting




#### Option 3 Pole Mounting




#### 2.3 Install microSD Card (Optional)






#### 2.4 Connect Alarm (Optional)



# **Chapter 3 Configuration**

Here is a typcial network topology. You can add and manage your devices via any of the methods.



## · Via NVR

The camera works with an NVR for easier batch access and management. Here we use a VIGI NVR as an example.

- 1. Connect your cameras to the same network as your NVR.
- 2. Power on your cameras with the PoE power supply or an external power supply.
- 3. Right click on the Live View screen on the monitor, and click Add Camera.
- Select your camera and click + to add your camera directly. If you have disabled Plug and Play on your NVR, create a password or use a preset password for your camera.

#### Note:

If you are using your cameras with other NVR brands, follow the steps below.

- 1. Power on your cameras and connect them to the network.
- 2. Activate the cameras using the TP-Link VIGI app or web management page.
- 3. Refer to the NVR's User Manual to add cameras.

#### Via VIGI App

You can remotely view live video, manage device, and get instant alerts via VIGI app.

1. Download and install the latest TP-Link VIGI app.



- 2. Open the app and log in with your TP-Link ID. If you don't have an account, sign up first.
- 3. Tap the + button on the top right and follow the app instructions to add your NVR.

#### · Via Web

You can view live video and modify camera settings via a web browser.

- 1. Find the camera's IP address on your router's client page.
- 2. On your local computer, open a web browser and enter https:// camera's IP address (https://192.168.0.60 by default).
- 3. Select your Country/Region and Time Zone.
- 4. Set a password to activate the camera.

# Appendix FAQ

#### Q1. What can I do if no cameras are discovered?

- Refresh to discover your camera again.
- Make sure the camera is powered on.
- Make sure your camera and NVR/computer are in the same subnet. If not, use the VIGI Config Tool to set camera's network parameters.
- Try to add your camera manually.
- For other NVR brands, make sure you have activated the camera by setting a password via the TP-Link VIGI app or web management page.

#### Q2. What should I do if I forgot the password of the camera?

- You can check the password of the camera via VIGI NVR, or its web management page. For more details, refer to the corresponding user guides.
- You can reset the camera and activate it again. During the activation process, you can set a new password.

#### Q3. What should I do if the SD card is not working properly?

- Make sure you are using a microSD card.
- Unplug the SD card and insert it again. Make sure you have inserted the SD card correctly.
- It's recommended to use a Class 10 microSD card or higher, with storage from 8 GB to 512 GB.
- Make sure you have initialized the microSD card via the TP-Link VIGI app or web management page.
- If the problem still persists, contact our technical support.

If you have more questions, please visit https://www.tp-link.com/support/faq/2850/.